eMachines D720/D520 Series

Quick Guide

Copyright © 2008. Acer Incorporated. All Rights Reserved. eMachines D720/D520 Series Quick Guide Original Issue: 08/2008 Changes may be made periodically to the information in this publication without obligation to notify any person of such revisions or changes. Such changes will be incorporated in new editions of this manual or supplementary documents and publications. This company makes no representations or warranties, either expressed or implied, with respect to the contents hereof and specifically disclaims the implied warranties of merchantability or fitness for a particular purpose. Record the model number, serial number, purchase date and place of purchase information in the space provided below. The serial number and model number are recorded on the label affixed to your computer. All correspondence concerning your unit should include the serial number, model number and purchase information. No part of this publication may be reproduced, stored in a retrieval system, or transmitted, in any form or by any means, electronically, mechanically, by photocopy, recording or otherwise, without the prior written permission of Acer Incorporated. eMachines D720/D520 Series Notebook PC Model number: _____

eMachines and the eMachines logo are registered trademarks of Acer Incorporated. Other companies' product names or trademarks are used herein for identification purposes only and belong to their respective companies.

Serial number: ___

Place of purchase: _____

First things first

We would like to thank you for making an eMachines notebook your choice for meeting your mobile computing needs.

Your guides

To help you use your eMachines notebook, we have designed a set of guides: First off, the **Just for Starters...** poster helps you get started with setting up your computer.

The **eMachines Generic User Guide** contains useful information applying to all models in the eMachines product series. It covers basic topics such as eMachines Recovery Management, using the keyboard, audio, etc. Please understand that due to its nature, the **Generic User Guide** as well as the **eMachinesSystem User Guide** mentioned below will occasionally refer to functions or features which are only contained in certain models of the series, but not necessarily in the model you purchased. Such instances are marked in the text with language such as "only for certain models".

The **Quick Guide** introduces you to the basic features and functions of your new computer. For more on how your computer can help you to be more productive, please refer to the **eMachinesSystem User Guide**. This guide contains detailed information on such subjects as system utilities, data recovery, expansion options and troubleshooting. In addition it contains warranty information and the general regulations and safety notices for your notebook. It is available in Portable Document Format (PDF) and comes preloaded on your notebook. Follow these steps to access it:

- 1 Click on **Start, All Programs, eMachinesSystem**.
- 2 Click on eMachinesSystem User Guide.




Note: Viewing the file requires Adobe Reader. If Adobe Reader is not installed on your computer, clicking on **eMachinesSystem User Guide** will ruthe Adobe Reader setup program first. Follow the instructions on the screen to complete the installation. For instructions on how to use Adobe Reader, access the **Help and Support** menu.

Your eMachines notebook tour

After setting up your computer as illustrated in the **Just for Starters...** poster, let us show you around your new eMachines notebook.

Top view



#	ICON	Item	Description
1	100	Microphone	Internal microphone for sound recording.

#	ICON	Item	Description
2		Integrated webcam	Web camera for video communication. (for selected models)
3		Display screen	Also called Liquid-Crystal Display (LCD), displays computer output.
4	Ф	Power button	Turns the computer on and off.
5	<i>Ö</i>	Wireless LAN communication button/indicator	Enables/disables the wireless LAN function. Indicates the status of wireless LAN communication.
6		Speakers	Left and right speakers deliver stereo audio output.
7		Keyboard	For entering data into your computer.
8		Palmrest	Comfortable support area for your hands when you use the computer.
9		Touchpad	Touch-sensitive pointing device which functions like a computer mouse.
10		Click buttons (left and right)	The left and right buttons function like the left and right mouse buttons.
11	*	Power ¹	Indicates the computer's power status.
	₫	Battery ¹	Indicates the computer's batttery status. 1. Charging: The light shows amber when the battery is charging. 2. Fully charged: The light shows green when in AC mode.
	>	HDD	Indicates when the hard disk drive is active.
	1	Num Lock	Lights up when Num Lock is activated.
	Ā	Caps Lock	Lights up when Caps Lock is activated.

^{1.} The front panel indicators are visible even when the computer cover is closed up.

Closed front view



#	Item	Description
1	Latch	Locks and releases the lid.

Rear view



#	Item	Description
1	Ventilation slots	Enable the computer to stay cool, even after prolonged use.

Left view




#	lcon	Item	Description
1	용	Ethernet (RJ-45) port	Connects to an Ethernet 10/100-based network.
2		External display (VGA) port	Connects to a display device (e.g., external monitor, LCD projector).
3	● ✓•+	USB 2.0 port	Connect to USB 2.0 devices (e.g., USB mouse, USB camera).
4	(+))	Line-in jack	Accepts audio line-in devices (e.g., audio CD player, stereo walkman, mp3 player)
5	Le ₁₀	Microphone-in jack	Accepts input from external microphones.
6	ဂ	Headphones/ speaker/line-out jack	Connects to audio line-out devices (e.g., speakers, headphones).

Right view



#	lcon	Item	Description
1	ĸ	Kensington lock slot	Connects to a Kensington-compatible computer security lock.
			Note: Wrap the computer security lock cable around an immovable object such as a table or handle of a locked drawer. Insert the lock into the notch and turn the key to secure the lock. Some keyless models are also available.
2		Optical drive	Internal optical drive; accepts CDs or DVDs
3		Optical disk access indicator	Lights up when the optical drive is active.
4		Optical drive eject button	Ejects the optical disk from the drive.
5		Emergency eject hole	Ejects the optical drive tray when the computer is turned off.
			Note: Insert a paper clip to the emergency eject hole to eject the optical drive tray when the computer is off.
6		DC-in jack	Connects to an AC adapter.

Base view



#	lcon	Item	Description
1	<u>+</u>	Battery bay	Houses the computer's battery pack.
2		Battery release latch	Releases the battery for removal.
3		Memory compartment	Houses the computer's main memory.
4		Hard disk bay	Houses the computer's hard disk (secured with screws).
5		Battery lock	Locks the battery in position.
6		Ventilation slots and cooling fan	Enable the computer to stay cool, even after prolonged use. Note: Do not cover or obstruct the opening of the fan.

Specifications

Operating	Genuine Windows Vista®	—
system		
Platform	Intel [®] Pentium [®] dual-core processor*	
	• Intel [®] Celeron [®] processor*	
	Mobile Intel® GL40 Express Chipset	
	• IEEE 802.11b/g	
System memory	Dual-channel support	
	$\bullet \hspace{0.4cm}$ Up to 2 GB of DDR2 667 MHz memory, upgradeable	
-	to 4 GB using two soDIMM modules	
Display	• 14.1" WXGA 1280 x 800	
Graphics	• Mobile Intel® GL40 Express Chipset	
Storage	• 2.5" hard disk drive	
subsystem	Optical drive option:	
	 DVD-Super Multi double-layer drive* DVD/CD-RW combo drive* 	
Audio	Two built-in stereo speakers	
Addio	High-definition audio support	
	MS-Sound compatible	
	Built-in microphone	
Communication	Integrated webcam*	
	• WLAN: IEEE 802.11b/g	
	LAN: Fast Ethernet; Wake-on-LAN ready	
Dimensions	• 340.4 (W) x 247 (D) x 22.9/42.3 (H) mm (13.4 x 9.7 x 0.9/1.6 inches)	
	• 2.40 kg (5.29 lbs.) with 6-cell battery pack	
Privacy control	BIOS user, supervisor, HDD passwords	_
	Kensington lock slot	
Power	• ACPI 3.0	
subsystem	• 48.8 W 4400 mAh	
	• 3-pin 65 W AC adapter	
	ENERGY STAR® 4.0*	
Special keys	88-/89-key keyboard	
and controls	Touchpad pointing device	

	 External display (VGA) port Headphones/speaker/line-out jack
	 Headphones/speaker/line-out iack
	Microphone-in jack
	• Line-in jack
	Ethernet (RJ-45) port
	DC-in jack for AC adapter
Environment	 Temperature: Operating: 5 °C to 35 °C Non-operating: -20 °C to 65 °C Humidity (non-condensing): Operating: 20% to 80% Non-operating: 20% to 80%



Note: * Only for certain models.



Note: The specifications listed above are for reference only. The exact configuration of your PC depends on the model purchased.